

HYBRI-FLEX® EQ

The following information is to be used as a guideline for the installation of the Hybri-Flex EQ flooring system. Contact the Sherwin-Williams Technical Service Department for assistance prior to application.

APPLICATION INFORMATION — SURFACE PREP PROFILE CSP 3-4

VOC MIXED	APPLICATION STEP	MATERIAL	MIX RATIO	THEORETICAL COVERAGE PER COAT	PACKAGING
0 g/L	Primer	Poly-Crete TF	A, B & C unit	90 sq ft/unit	0.80 gal/unit
0 g/L 0	Basecoat	Poly-Crete SL 5900F	A, B & C unit To Excess	40-42 sq ft/unit 800 lbs/1000 sq ft	3.125 gal/unit 50 lbs
0 g/L 0	Second Broadcast	Resufloor Glaze 5900F	2:1 To Excess	90 sq ft/gal 500 lbs/1000 sq ft	3, 15 or 150 gals 50 lbs
0 g/L	Grout	Resufloor Glaze	2:1	90 sq ft/gal	3, 15 or 150 gals
0 g/L	Topcoat	Resutile AT	Premeasured unit	550-775 sq ft/kit	1.125-1.5 gal/unit 2 lbs

For additional topcoat options, contact your Sherwin-Williams Representative.

IMPORTANT!

Read these instructions carefully several days prior to starting your work. Seek answers to any questions you may have before you begin. Sherwin-Williams HPF maintains a technical staff that will be glad to answer your questions and give you advice pertaining to your particular installation.

SYSTEM OVERVIEW

Hybri-Flex EQ is a 100% solids low odor color quartz system composed of a 1/8" Poly-Crete SL body coat with a decorative quartz broadcast. It uses a Resufloor Glaze broadcast coat, Resufloor Glaze grout coat and a Resutile AT topcoat, yielding a total nominal system thickness of 1/4".

SURFACE PREPARATION

Surface should be profiled, clean, dry, oil free and sound. Shot Blasting is the preferred preparation method. Please refer to the master Surface Preparation Guide on our website for more information. Never feather edge Hybri-Flex EQ, always terminate in a keyway groove at doorways, drains and exposed edges. No epoxy coatings should be applied unless surface temperature is a minimum of 5°F above dew point. See Dew Point Calculation Chart on our website for detailed instructions.

MOISTURE CONCERNS

Please refer to the Floor Evaluation Guidelines in the Contractor's Center of our website for a step-by-step process to determine the condition of the concrete.

MIXING AREA

Select a convenient mix area and protect the surface from spillage by covering it with a sheet of plastic and a layer of cardboard. Be generous with the amount of space allocated for this function. The more comfortably your mixer works, the less likely you are to have a "mix error". Please refer to our Mix Station video on our website for more information.

STORAGE CONDITIONS

Poly-Crete SL must be stored dry. Exposure of the aggregate to moisture for an extended period will cause lumps. Do not allow resins to freeze. The shelf life is 6 months from the ship date in the original unopened container. Products must be stored in temperatures no less than 60°F and no greater than 85°F.

JOINT GUIDELINES

Refer to the Joint Guidelines for complete details on our website.

APPLICATION METHOD

Proper planning is essential for satisfactory appearance of the finished floor. Lay out installation in sections to allow full width to be finished in 20 minutes (@70°F) or less to assure absence of placement lines.

PRIMER

In most applications, Hybri-Flex EQ does not require a primer. However, very porous substrates should be primed first with Poly-Crete TF Plus.

- A. Poly-Crete TF Plus is supplied in pre-measured units consisting of one pail of resin, one container of hardener and one bag of aggregate (powder). Pour the Poly-Crete TF Plus resin into a 2-gallon pail; scrape the bottom and sides with a mix stick to assure that all material is transferred to the mix bucket. Use the Poly-Crete pail to scrape the mix stick, never scrape the mix stick on the side of the mix pail. Measure 0.25 fluid oz of Poly-Crete HF Accelerator and add it to the mix bucket and mix for 1 minute. Pour the entire Poly-Crete TF hardener into the center of the mix bucket. Using a ½" 850 RPM drill with a 4" dispersion blade, mix the resin and hardener for 30 seconds. Slowly add the Poly-Crete TF aggregate to the resin and hardener and mix at 850 RPM for 1 minute. **PRODUCT MUST BE MIXED WITH A 4" DISPERSION BLADE AND A ½" VARIABLE SPEED 850 RPM DRILL. *DO NOT ADD HARDENER TO RESIN UNTIL BATCH IS READY FOR MIXING*. *FAILURE TO ADD ALL POLY-CRETE TF PLUS POWDER WILL RESULT IN IMPROPER CURE OF MATERIAL***
- B. Pour the entire batch onto the floor in a 4" to 6" ribbon. Using an 18" 3/8" nap roller, roll the material at 90 square feet per kit. Cross roll the material to ensure there are no puddles. Allow to cure for 6 hours @ 70°F.

BASECOAT

- A. Poly-Crete SL is supplied in pre-measured units consisting of one pail of resin, one container of hardener and one bag of aggregate (powder). Pour the Poly-Crete SL resin into a metal 5-gallon pail; scrape the bottom and sides with a mix stick to assure that all material is transferred to the mix bucket. Use the Poly-Crete pail to scrape the mix stick; never scrape the mix stick on the side of the mix pail. Pour the entire Poly-Crete SL hardener into the center of the mix bucket. Next, using a ½" 850 RPM drill with a 4" dispersion blade, mix the resin and hardener for 30 seconds. Slowly add the Poly-Crete SL aggregate to the resin and hardener and mix at 850 RPM for 1 minute. **PRODUCT MUST BE MIXED WITH A 4" DISPERSION BLADE AND A ½" VARIABLE SPEED 850 RPM DRILL. *DO NOT ADD HARDENER TO RESIN UNTIL BATCH IS READY FOR MIXING*. *FAILURE TO ADD ALL POLY-CRETE SL AGGREGATE WILL RESULT IN IMPROPER CURE OF MATERIAL***
- B. Pour the entire batch onto the floor and spread with a ½ V notched squeegee. Each kit of Poly-Crete SL will yield 40-42 square feet per kit. Check squeegee every 1,000 square feet for wear. Have a new squeegee ready to avoid interruption in the process.
- C. Use a flat trowel to cut in edges, drains and around equipment. For continuity of finish and to ensure that new batches of material are blended together without transition lines, use even pressure and trowel at a low angle using a sweeping motion.
- D. To remove squeegee lines and help the material level, immediately Loop Roll the material after it has been placed. The material should be rolled straight forward and back, picking up the roller with each pass; this will avoid leaving divots in the floor. After the squeegee lines have been removed, the floor should be cross rolled side to side along the entire wet edge. The final cross roll should be completed within 12 minutes of mixing the product at 70°F.
- E. Wear spiked shoes and broadcast 5900F color quartz aggregate up into the air and let it fall onto the floor. Make sure the broadcast is dispersed evenly over the entire floor area at a rate of 0.8 lbs per square foot. Wait 15 minutes from the start of the mix before beginning the broadcast and complete broadcasting within 30 minutes from the start of the mix. Do not roll or walk back into areas that have been broadcast. Allow Poly-Crete SL to cure for a minimum of 8 hours @ 70°F.
- F. Use a stiff bristle broom to sweep off excess aggregate. Use a vacuum to remove the sand around the edges and corners that are not accessible with a broom.

SECOND BROADCAST

- A. Measure out 1 part Resuflor Glaze Regular or FAST hardener, and 2 parts Resuflor Glaze Resin. First add the hardener into a separate mixing pail and then add the resin. Scrape the bottom and sides with a mix stick to ensure that all material is transferred to the mix bucket. Use the measuring pail to scrape the mix stick, and never scrape the mix stick on the side of the mix pail.
- B. Using a ½" 450 RPM drill with a Jiffler blade, mix the resin and hardener for 2 minutes. ***DO NOT ADD RESIN TO HARDENER UNTIL BATCH IS READY FOR MIXING***
- C. Pour a 4" to 6" ribbon along the starting area. Use a 3" chip brush to cut in along edges, doorways and drains.
- D. Using a 12" flat soft rubber window squeegee, pull the material from side to side, overlapping passes every 6". Be careful not to leave any puddles. Resuflor Glaze is applied at 90 square feet per gallon over 5900F, and 50 square feet per gallon over 5900C.
- E. Wear spiked shoes while back rolling the material against the squeegee lines with a high-quality delinted 3/8" nap roller.
- F. Cross roll the material side to side, overlapping the previous pass with half the roller width.
- G. Broadcast aggregate up into the air and let it fall onto the floor. Make sure the broadcast is dispersed evenly over the entire floor area at a rate of 0.5 lbs per square foot. Do not roll or walk back into areas that have been broadcast. Allow Resuflor Glaze to cure for 4 hours @ 70°F.
- H. Use a stiff bristle broom to sweep off excess aggregate. Use a vacuum to remove sand around the edges and corners that are not accessible with a broom.

GROUT COAT

- A. Measure out 1 part Resuflor Glaze Regular hardener, and 2 parts Resuflor Glaze Resin. First add the hardener to a separate mixing pail and then add the resin. Scrape the bottom and sides with a mix stick to assure that all material is transferred to the mix bucket. Use the measuring pail to scrape the mix stick; never scrape mix stick on the side of the mix pail.
- B. Using a ½" 450 RPM drill with a Jiffler blade, mix the resin and hardener for 2 minutes. ***DO NOT ADD RESIN TO HARDENER UNTIL BATCH IS READY FOR MIXING***
- C. Pour a 4" to 6" ribbon along the starting area. Use a 3" chip brush to cut in along edges, doorways and drains.
- D. Using a 12" flat soft rubber window squeegee, pull the material from side to side, overlapping passes every 6". Be careful not to leave any puddles. Resuflor Glaze is applied at 90 square feet per gallon over 5900F and 50 square feet per gallon over 5900C.

- E. Wear spiked shoes and back roll the material against the squeegee lines with a high-quality 3/8" nap roller.
- F. Cross roll the material side to side, overlapping the previous pass with half the roller width. Allow to cure for 10 hours @70°F.

TOPCOAT INSTRUCTIONS

(1 coat for standard finish, 2 coats for orange peel texture, 3 coats for a smooth finish)

RESUTILE AT TOPCOAT SPREAD RATES

Gloss Clear (w/grit) = 575 SF/kit	Satin Clear (w/grit) = 775 SF/kit
Gloss Clear (no grit) = 550 SF/kit	Satin Clear (no grit) = 750 SF/kit

NOTE: Resutile AT is sold in kits only. Spread rates vary due to differences in gloss and satin kit sizes.

- A. Pour 1 gallon of Resutile AT hardener into a 2 gallon bucket. Add the Resutile AT resin and mix for 30 seconds. If additional abrasion resistance is required, slowly add the bag of Resutile AT Grit and continue mixing for an additional minute. Pour a small amount into a dip and roll tray that is large enough to accommodate an 18" roller.
- B. Dip roller cover into paint tray and roll off excess. Apply two 8-10 foot long paths from left to right then right to left. Re-wet roller and continue application. Even out roller lines by using W-shaped crosses and/or up and down passes. If not even, re-roll up and down until uniform. A final cross roll is necessary to even out roller lines. Make sure to complete this roll within 10 minutes of the coating being placed.
- C. To prevent settling of the grit/powder, occasionally remix Resutile AT in a tray or bucket with a stick. Dry time is dependent on humidity as well as temperature.
- D. If recoating over 24 hours, sand floor using at least a 60 grit screen, solvent wipe and apply Resufloor Glaze epoxy with Super Stick additive at recommended rate. Re-apply Resutile AT the next day.

NOTE: This product is best suited for application in temperatures between 60°F and 85°F. Full chemical and abrasion resistance occurs in 7 days at 77°F. These properties will be attained more slowly at lower temperatures. Protect floor from chemical exposure and abrasive wear during this time

IMPORTANT!

Before using Sherwin-Williams High Performance Flooring products, read and understand their accompanying Safety Data Sheet.

STANDARD TERMS AND CONDITIONS OF SALE, INCLUDING STANDARD WARRANTY APPLY - VISIT industrial.sherwin-williams.com/na/us/en/resin-flooring FOR THE LATEST VERSION.

CAUTION! As with all chemical products, individuals may have different reactions to exposure to specific products. This is dependent upon many factors, including the individual's personal characteristics, the size of the installation, the ventilation available, the intensity of the exposure or the length of the exposure. Individuals may experience discomfort during the installation process of one product, but not another.

In some cases this is experienced as a skin irritation and in others it is experienced as an inhalant irritation. Typically, it disappears once the exposure is eliminated. In some cases people can become "sensitized" to a product and experience the discomfort every time there is exposure without Personal Protective Equipment ("PPE").

To protect yourself from various exposures or discomfort during the mixing and application of our products, we recommend covering exposed skin including using gloves, long sleeves, safety glasses and a respirator such as the 3M 8577 P95 Universal Disposable Carbon Respirator or a cartridge respirator.

Use only as directed. KEEP OUT OF REACH OF CHILDREN.

Do not reseal moisture-contaminated hardener. This will result in carbon dioxide generation or possible violent rupture of container.

THE SHERWIN-WILLIAMS DIFFERENCE

Sherwin-Williams High Performance Flooring delivers world-class industry subject matter expertise, unparalleled technical and specification service, and unmatched regional commercial team support to our customers around the globe.

United States & Canada

sherwin-williams.com/resin-flooring
swflooring@sherwin.com

©2025 The Sherwin-Williams Company
High Performance Flooring
HPF-1530952-08 09/25