

RESUDECK™ II

The following information is to be used as a guideline for the installation of the Resudeck II flooring system. Contact the Sherwin-Williams Technical Service Department for assistance prior to application.

APPLICATION INFORMATION — SURFACE PREP PROFILE CSP 3-4

VOC MIXED	APPLICATION STEP	MATERIAL	MIX RATIO	THEORETICAL COVERAGE PER COAT	PACKAGING
<100 g/L	Primer	Resudeck MPB	4/1	300 sq ft/gal	10 gals
<100 g/L	Basecoat/Membrane	Resudeck MPB	4 / 1	80 sq ft/gal	5 gals
0 g/L	Broadcast	16-30 Mesh Silica Sand	N/A	30 lbs/100 sq ft	50 lbs
<100 g/L	Topcoat	Resudeck FLA ~	Premeasured kit	80 sq ft/gal	4.4 gals

INSTALLATION

Sherwin-Williams High Performance Flooring materials shall only be installed by approved contractors.

SURFACE PREPARATION – GENERAL

Sherwin-Williams systems can be applied to a variety of substrates if the substrate is properly prepared. Preparation of surfaces other than concrete will depend on the type of substrate, such as wood, concrete block, quarry tile, etc. Should there be any questions regarding a specific substrate or condition, please contact the Sherwin-Williams Technical Service Department prior to starting the project. Refer to Surface Preparation Form G-1.

SURFACE PREPARATION – CONCRETE

Concrete surfaces shall be abrasive blasted to remove all surface contaminants and laitance. The prepared concrete shall have a surface profile depending upon the system selected. Refer to Form G-1.

After initial preparation has occurred, inspect the concrete for bug holes, voids, fins and other imperfections. Protrusions shall be ground smooth while voids shall be filled with a system-compatible filler. For recommendations, consult the Sherwin-Williams Technical Service Department.

TEMPERATURE

Throughout the application process, substrate temperature should be 60°F-90°F. Substrate temperature must be at least 5°F above the dew point. Applications on concrete substrate should occur while temperature is falling to lessen offgassing. The material should not be applied in direct sunlight, if possible. Protect material from freezing prior to installation.

GENERAL PRODUCT INFORMATION

OPTIONS

Resudeck systems are available in Tan, Light Gray, Medium Gray, Dark Gray and White. For a clear elastomeric coating product, see Resudeck FLA Clear.

LIMITATIONS

Concrete must exhibit 3000 psi minimum strength. Concrete surfaces to be coated must be free of loose particles and shall be without ridges, projections, voids and concrete droppings that would be mechanically detrimental to coating application or function.

New concrete must be cured for 28 days.

Uncured materials are sensitive to heat and moisture.

PRIMER – RESUDECK MPB

COVERAGE RATE: 1 gallon of Resudeck MPB will cover: 300 square feet at 5.3 mils wet/dry film.

PREMIX PART A AND PART B using a Jiffy® mixer blade and slow-speed drill to ensure materials are homogeneous.

COMBINE AND MIX 4 Parts resin to 1 part hardener by volume. Use separate measuring containers and pour into a mixing pail. Mix only what can be applied in 30 minutes.

APPLY RESUDECK MPB at the rate of 300 square feet/gallon with an airless sprayer. DO NOT puddle material. For proper appearance and development of physical properties, it is crucial that material is not applied above or below this rate. A 3/8" nap phenolic resin core roller may also be used. Dip the roller in the coating and lightly roll out excess in the application tray. Apply two 8- to 10-foot-long paths on the concrete, making one stroke left to right and one right to left. Rewet the roller and apply two more paths adjacent to the first pair. Rewet the roller and apply a third pair adjacent to the second.

SPREAD THE MATERIAL evenly with V-shaped cross passes.

MAKE SURE THE FLOOR HAS JUST ENOUGH COATING TO COVER EVENLY. Dry roll to remove any excess material. Excess material will cause the floor to dry unevenly and could cause the floor to blister, especially in high humidity. Insufficient material will cause the floor to look non-uniform.

LEVEL THE AREA with straight passes that cross the initial material paths.

ALLOW RESUDECK MPB TO BECOME THUMBPRINT TACKY before proceeding to Basecoat Application—Resudeck MPB (low VOC).

Seal all cracks and joints flush with PolyTuff PTS E-101 Joint Sealant.

NOTE: If the deck requires excessive crack and joint work, it may be advisable to prime only the areas that will receive the Resudeck FLT Tape, complete the joint work, and then prime the rest of the deck to ensure you do not miss the window for applying the Resudeck FHS (low VOC). On surfaces rougher than CSP-3, use a fabric tape in place of the Resudeck FLT Tape.

NOTE: If the Resudeck III system is to be applied over an existing system, use Resudeck FLP/U. See appropriate product data sheet or call Sherwin-Williams Technical Support.

BASECOAT/MEMBRANE – RESUDECK MPB

COVERAGE RATE: 1 gallon of Resudeck MPB will cover: 80 square feet at 20 mils wet/dry film.

PREMIX using a Jiffy mixer blade and slow-speed drill. (This is required.)

MIX THOROUGHLY UNTIL A HOMOGENEOUS MIXTURE AND COLOR ARE OBTAINED. Use care not to allow the entrapment of air into the mixture.

IMMEDIATELY POUR ALL OF THE MIXED MATERIAL onto the floor in a single bead. **NOTE:** The use of spiked shoes will allow freedom of movement on the wet floor.

CAUTION: The surface will be slippery.

PUSH THE 20 MIL NOTCHED SQUEEGEE at an even speed with down pressure to spread the material.

START THE SECOND AND REMAINING PASSES by pushing material parallel to the first stroke. Hold the bead of material near the center of the bar and push at an even speed with slight down pressure.

BACKROLL THE MATERIAL with a 3/8-inch nap roller for a smooth, uniform appearance.

BROADCAST – SILICA SAND

ALLOW RESUDECK MPB TO THICKEN UNTIL IT CAN BE BROADCAST WITH 16/30 MESH SILICA SAND WITHOUT THE SAND SINKING INTO THE MEMBRANE. Time for thickening is dependent on atmospheric conditions. The amount of sand used will vary. (Normal usage is 30 pounds per 100 square feet.)

TOPCOAT – RESUDECK FLA

NOTE: For decorative applications use Resudeck FLA. See appropriate product data sheet.

COVERAGE RATE: 1 gallon of Resudeck FLA will cover: 80 square feet at 20 mils wet/dry film.

PREMIX PART A using a Jiffy mixer blade and slow-speed drill.

ADD PART B AND MIX THOROUGHLY UNTIL A HOMOGENEOUS MIXTURE AND COLOR ARE OBTAINED. Use care not to allow the entrapment of air into the mixture.

IMMEDIATELY POUR ALL OF THE MIXED MATERIAL onto the floor in a single bead. **NOTE:** The use of spiked shoes will allow freedom of movement on the wet floor.

CAUTION: The surface will be slippery.

PUSH THE FLAT SQUEEGEE at an even speed with down pressure to spread the material.

START THE SECOND AND REMAINING PASSES by pushing material parallel to the first stroke. Hold the bead of material near the center of the bar and push at an even speed with slight down pressure.

BACKROLL THE MATERIAL with a 3/8" nap roller for a smooth, uniform appearance. Backrolling is required to even out squeegee lap marks/the coating mil thickness.

BROADCAST ADDITIONAL AGGREGATE AS NEEDED to cover any bare or insufficient aggregate placement.

OPTIONAL 2ND TOPCOAT – RESUDECK FLA

Ramps, turn radii and drive lanes typically require two coats to increase durability. Some applications may also require two coats to meet project specifications. Using the "rain" method, broadcast #16 aluminum oxide at a rate of 1-2 pounds per 100 square feet. **DO NOT BACKROLL.**

IF SECOND COAT IS REQUIRED, REPEAT THE STEPS ABOVE for mixing/application instructions.

COVERAGE RATE: 1 gallon of Resudeck FLA will cover: 125 square feet at 12.8 mils wet/dry film.

At 77°F and 50 percent relative humidity, allow coating to cure a minimum of 2-4 hours before proceeding to subsequent coats. To obtain proper adhesion between coats, it is imperative that recoating be done within 24 hours. If more than 24 hours pass between coats, reprime with Resudeck FLP/U.

ALLOW 24 HOURS BEFORE PERMITTING LIGHT PEDESTRIAN TRAFFIC AND AT LEAST 72 HOURS BEFORE PERMITTING HEAVY PEDESTRIAN OR VEHICULAR TRAFFIC ONTO THE FINISHED SURFACE.

CLEANUP

Clean up mixing and application equipment immediately after use. Use toluene or xylene. Observe all fire and health precautions when handling or storing solvents.

SAFETY PRECAUTIONS

Refer to the safety data sheet before use. Published technical data and instructions are subject to change without notice. Contact your Sherwin-Williams representative for additional technical data and instructions.

MATERIAL STORAGE

Store materials in a temperature-controlled environment of 40°F-90°F and out of direct sunlight. Keep resins, hardeners and solvents separated from each other and away from sources of ignition.

MAINTENANCE

Occasional inspection of the installed material and spot repair can prolong system life. For specific information, contact the Sherwin-Williams Technical Service Department.

DISCLAIMER

The information and recommendations set forth in this document are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication.

Consult www.sherwin-williams.com/resin-flooring to obtain the most recent product data information and application instructions.

WARRANTY

The Sherwin-Williams Company warrants our products to be free of manufacturing defects in accord with applicable Sherwin-Williams quality control procedures. Liability for products proven defective, if any, is limited to replacement of the defective product or the refund of the purchase price paid for the defective product as determined by Sherwin-Williams.

NO OTHER WARRANTY OR GUARANTEE OF ANY KIND IS MADE BY SHERWIN-WILLIAMS, EXPRESSED OR IMPLIED, STATUTORY, BY OPERATION OF LAW OR OTHERWISE, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

IMPORTANT!

Before using Sherwin-Williams High Performance Flooring products, read and understand their accompanying Safety Data Sheet.

STANDARD TERMS AND CONDITIONS OF SALE, INCLUDING STANDARD WARRANTY APPLY - VISIT industrial.sherwin-williams.com/na/us/en/resin-flooring FOR THE LATEST VERSION.

CAUTION! As with all chemical products, individuals may have different reactions to exposure to specific products. This is dependent upon many factors, including the individual's personal characteristics, the size of the installation, the ventilation available, the intensity of the exposure or the length of the exposure. Individuals may experience discomfort during the installation process of one product, but not another.

In some cases this is experienced as a skin irritation and in others it is experienced as an inhalant irritation. Typically, it disappears once the exposure is eliminated. In some cases people can become "sensitized" to a product and experience the discomfort every time there is exposure without Personal Protective Equipment ("PPE").

To protect yourself from various exposures or discomfort during the mixing and application of our products, we recommend covering exposed skin including using gloves, long sleeves, safety glasses and a respirator such as the 3M 8577 P95 Universal Disposable Carbon Respirator or a cartridge respirator.

Use only as directed. KEEP OUT OF REACH OF CHILDREN.

Do not reseal moisture-contaminated hardener. This will result in carbon dioxide generation or possible violent rupture of container.

THE SHERWIN-WILLIAMS DIFFERENCE

Sherwin-Williams High Performance Flooring delivers world-class industry subject matter expertise, unparalleled technical and specification service, and unmatched regional commercial team support to our customers around the globe.

United States & Canada

sherwin-williams.com/resin-flooring
swflooring@sherwin.com

©2025 The Sherwin-Williams Company
High Performance Flooring
HPF-1530952-08 07/25