



RESINOUS FLOORING

EPO-FLEX @ 20 MILS WITH FIBERGLASS SCRIM CLOTH, INSTALL 12" WIDE (6" ON EACH SIDE OF THE JOINT)

1/8" -1/4" WIDE SAW CUT (BY OTHERS) PLACE SAND OR BACKER ROD THEN FILL WITH EPO-FLEX

ONCRETE COLD JOINT DETAIL

NTS

SHERWIN- WILLIAMS

TYPICAL FLOORING DETAIL CONCRETE COLD JOINT

J4