



RESINOUS FLOORING

EPO-FLEX @ 20 MILS WITH
FIBERGLASS SCRIM CLOTH,
INSTALL 12" WIDE (6" ON EACH
SIDE OF THE JOINT)

$\frac{1}{8}$ " - $\frac{1}{4}$ " WIDE SAW CUT (BY OTHERS)
PLACE SAND OR BACKER ROD
THEN FILL WITH EPO-FLEX

J4 CONCRETE COLD JOINT DETAIL
NTS

SHERWIN- WILLIAMS TYPICAL FLOORING DETAIL CONCRETE COLD JOINT	J4
---	-----------