



$D = W/2$
 $D = \text{DEPTH OF BACKER ROD}$
 $W = \text{WIDTH OF EXPANSION JOINT}$

**SHERWIN
WILLIAMS®**

HIGH
PERFORMANCE
FLOORING

sherwin-williams.com/resinflooring
(660) 638-5089

TITLE

ACCELERERA C, Q, B, HC, HQ, HB
EXPANSION JOINT DETAIL

DATE

6 / 15

SCALE

NTS

DWG NO.

AF-3

PROJECT