



$D = W/2$
 $D = \text{DEPTH OF BACKER ROD}$
 $W = \text{WIDTH OF JOINT}$

SHERWIN
WILLIAMS. | HIGH
 PERFORMANCE
 FLOORING

www.sherwin-williams.com/resinflooring
 660-638-5089

TITLE

HYBRI-FLEX

PIPE / DUCT BREACHE DETAIL

DATE

10 / 11

SCALE

AS NOTED

DWG NO.

HF-15

PROJECT