



$D = W/2$   
 $D = \text{DEPTH OF BACKER ROD}$   
 $W = \text{WIDTH OF JOINT}$

**SHERWIN  
WILLIAMS®**

HIGH  
PERFORMANCE  
FLOORING

[sherwin-williams.com/resinflooring](http://sherwin-williams.com/resinflooring)  
 (660) 638-5089

**TITLE**

**POLY-CRETE MD, MDB, MDC, MDQ**

PIPE / DUCT BREACHE DETAIL

**DATE**

10 / 11

**SCALE**

AS NOTED

**DWG NO.**

PCMD-13

**PROJECT**