



$D = W/2$   
 D = DEPTH OF BACKER ROD  
 W = WIDTH OF JOINT

**SHERWIN  
WILLIAMS®**

HIGH  
PERFORMANCE  
FLOORING

sherwin-williams.com/resinflooring  
 (660) 638-5089

**TITLE**

**POLY-CRETE SLB**

PIPE / DUCT BREACHE DETAIL

**DATE**

10 / 11

**SCALE**

AS NOTED

**DWG NO.**

PCSL-14

**PROJECT**