



$D = W/2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF JOINT

**SHERWIN
WILLIAMS®**

HIGH
PERFORMANCE
FLOORING

sherwin-williams.com/resinflooring
 (660) 638-5089

TITLE

HYBRI-FLEX

ISOLATION JOINT DETAIL WITH COVE

DATE

3/25

SCALE

AS NOTED

DWG NO.

HF-7

PROJECT