

D = W/2 D = DEPTH OF BACKER ROD W = WIDTH OF EXPANSION JOINT



sherwin-williams.com/resinflooring (660) 638-5089

	POLY-CRETE FLOORING EXPANSION JOINT DETAIL		
	DATE	SCALE AS NOTED	
	PCHF-3	PROJECT	