



10
A125

SMOOTH FLOOR TRANSITION

3" = 1'-0"

**SHERWIN
WILLIAMS.**

HIGH
PERFORMANCE
FLOORING

sherwin-williams.com/resinflooring
(660) 638-5089

TITLE

POLY-CRETE FLOORING

TRANSITION TO POLISHED CONCRETE

DATE

2/25

SCALE

AS NOTED

DWG NO.

PCMD-18D

PROJECT