

D = W /2 D = DEPTH OF BACKER ROD W = WIDTH OF EXPANSION JOINT



sherwin-williams.com/resinflooring (660) 638-5089

POLY-CRETE EXPANSION JOINT DETAIL DATE 2/25 DWG NO. PCMD-3 PROJECT