

D = W/2 D = DEPTH OF BACKER ROD W = WIDTH OF EXPANSION JOINT



sherwin-williams.com/resinflooring (660) 638-5089

POLY-CRETE SLB	
EXPANSION JOINT DETAIL	
DATE 10 / 11	SCALE AS NOTED
PCSL-3	PROJECT