

D = W/2

D = DEPTH OF BACKER ROD

W = WIDTH OF EXPANSION JOINT



sherwin-williams.com/resinflooring (660) 638-5089

TITLE	POLY-CRETE SLB EXPANSION JOINT WITH REINFORCEMENT DETAIL	
DATE		SCALE

AS NOTED

DWG NO.

PCSL-3A

PROJECT