



$D = W / 2$   
 D = DEPTH OF BACKER ROD  
 W = WIDTH OF JOINT

**SHERWIN WILLIAMS®** | HIGH PERFORMANCE FLOORING

[sherwin-williams.com/resinflooring](http://sherwin-williams.com/resinflooring)  
 (660) 638-5089

TITLE		POLY-CRETE SLB	
		ISOLATION JOINT DETAIL	
DATE	10 / 11	SCALE	AS NOTED
DWG NO.	PCSL-6	PROJECT	