



$D = W/2$   
 D = DEPTH OF BACKER ROD  
 W = WIDTH OF JOINT

**SHERWIN  
WILLIAMS®**

HIGH  
PERFORMANCE  
**FLOORING**

[sherwin-williams.com/resinflooring](http://sherwin-williams.com/resinflooring)  
 (660) 638-5089

**TITLE**

**EPOXY FLOORING**

PIPE / DUCT BREACHE DETAIL

**DATE**

3/25

**SCALE**

AS NOTED

**DWG NO.**

EF-14

**PROJECT**