



$D = W / 2$   
 D = DEPTH OF BACKER ROD  
 W = WIDTH OF JOINT

**SHERWIN  
WILLIAMS®**

HIGH  
PERFORMANCE  
FLOORING

[sherwin-williams.com/resinflooring](http://sherwin-williams.com/resinflooring)  
 (660) 638-5089

TITLE

**EPOXY FLOORING**

ISOLATION JOINT DETAIL

DATE

3/25

SCALE

AS NOTED

DWG NO.

**EF-6**

PROJECT