



$D = W/2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF JOINT

SHERWIN
WILLIAMS. | HIGH
 PERFORMANCE
 FLOORING

www.sherwin-williams.com/resinflooring

660-638-5089

TITLE

EPOXY FLOORING

ISOLATION JOINT DETAIL WITH COVE

DATE

10 / 11

SCALE

AS NOTED

DWG NO.

EF-7

PROJECT