


## RESUFLOOR™ SCREED DECO FLAKE

**Sherwin-Williams Resufloor Screed Deco Flake** is a 3/16" - 1/4" decorative upgrade resurfacing system that utilizes epoxy and silica aggregate mortar, high build grout and seal coat, and selected vinyl chip aggregate for decorative appearance.



- 0 Primer
- 1 Mortar
- 2 Broadcast Bonding Coat
- 3 Grout
- 4 Seal Coat

### BENEFITS

- Protects substrates from heavy conditions of thermal shock, impact and wear
- Wide range of colors available
- Available with an antimicrobial agent
- Acceptable for use in USDA inspected facilities

### USES

- Locker rooms, restrooms
- Pharmaceutical
- Commercial

### TYPICAL PHYSICAL PROPERTIES

| Color  | Vinyl Chip Blends   |
|--|---|
| <b>Hardness</b> , Shore D ASTM D 2240                    | 80/65   |
| <b>Compressive Strength</b> ASTM C 579                   | 15,000 psi  |
| <b>Tensile Strength</b> ASTM C 307                       | 1,700 psi   |
| <b>Flux Flexural Strength</b> ASTM C 307                 | 3,700 psi   |
| <b>Adhesion</b> ACI 503R                                 | 300 psi concrete failure  |
| <b>Abrasion Resistance</b> ASTM D 4060 CS-17 Wheel 1,000 | 70-90 mgs lost  |
| <b>Impact Resistance</b> MIL-D-3134, Sec.4.7.3           | Withstands 16 ft lbs without cracking, delamination or chipping |
| <b>Flammability</b> ASTM E 648 Critical Radiant Flux     | Class I, 0.93   |

## INSTALLATION

Sherwin-Williams High Performance Flooring materials shall only be installed by approved contractors. The following information is to be used as a guideline for the installation of the Resuflored Screed Deco Flake. Contact the Sherwin-Williams Technical Service Department for assistance prior to application.

### SURFACE PREPARATION – GENERAL

Sherwin-Williams systems can be applied to a variety of substrates if the substrate is properly prepared. Preparation of surfaces other than concrete will depend on the type of substrate, such as wood, concrete block, quarry tile, etc. Should there be any questions regarding a specific substrate or condition, please contact the Sherwin-Williams Technical Service Department prior to starting the project. Refer to Surface Preparation Form G-1.

### SURFACE PREPARATION – CONCRETE

Concrete surfaces shall be abrasive blasted to remove all surface contaminants and laitance. The prepared concrete shall have a surface profile depending upon system selected. Refer to Form G-1.

After initial preparation has occurred, inspect the concrete for bug holes, voids, fins and other imperfections. Protrusions shall be ground smooth while voids shall be filled with a system compatible filler. For recommendations, consult the Sherwin-Williams Technical Service Department.

## TEMPERATURE

Throughout the application process, substrate temperature should be 50-90°F. Substrate temperature must be at least 5°F above the dew point. Applications on concrete substrate should occur while temperature is falling to lessen off gassing. The material should not be applied in direct sunlight, if possible. Protect material from freezing prior to installation.

## APPLICATION INFORMATION

| VOC MIXED     | APPLICATION STEP     | MATERIAL              | MIXED RATIO      | THEORETICAL COVERAGE PER COAT CONCRETE  | PACKAGING                   |
|---------------|----------------------|-----------------------|------------------|---|-----------------------------|
| <50 g/L       | Primer               | 3579                  | 2:1              | 250 sq. ft. / gal   | 3 or 15 gals                |
| <50 g/L<br>0  | Mortar               | 3561<br>5115          | 4:1              | 33 sq. ft. / 1/4 gal @ 1/4"<br>44 sq. ft. / 1/4 gal @ 3/16"<br>**70 lbs / 1/4 gal | 1.25 - 250 gals<br>50 lbs.  |
| <100 g/L<br>0 | Bonding<br>Broadcast | 3746<br>6750DB/6755DB | 2:1<br>to excess | 100 sq. ft. / gal<br>200 lbs / 1,000 sq. ft.                                      | 3 or 15 gals<br>50 lb. bags |
| <100 g/L      | Seal Coat            | 3746                  | 2:1              | 100 sq. ft./gal   | 3 or 15 gals                |

\*\* Additional 5115 aggregate may be added to 1/4 gallon of mixed epoxy to facilitate power troweling (10 lbs. recommended). For additional topcoat options, consult the Sherwin-Williams Topcoat Selection Guide or contact your Sherwin-Williams representative.

## PRIMER

### MIXING AND APPLICATION

1. Add 2 parts 3579 A (resin) to 1 part 3579 B (hardener) by volume. Mix with low-speed drill and Jiffy blade for three minutes until uniform. Apply via brush, roller or spray at a rate of 250 square feet per gallon (6 WFT mils). Wait for primer to become tacky (usually 1 hour minimum). This prevents primer from bleeding through and sliding during mortar placement. If primer cures for more than 4 hours, broadcast lightly but uniformly with clean, dry 40-60 mesh aggregate.

## MORTAR

### MIXING AND APPLICATION

1. Premix 3561 A (resin) using a low-speed drill and Jiffy blade. Mix for one minute until uniform, exercising caution not to whip air into the material.
2. Add 4 parts 3561A (4 quarts resin) to 1 part 3561B (1 quart hardener) by volume. Mix with low-speed drill and Jiffy blade for three minutes until uniform. Place mixed 3561 into mortar mixer. Slowly add 70 pounds of 5115 aggregate. Mix until aggregate is thoroughly 'wet out.' Immediately dump mortar onto substrate and screed to desired thickness.
3. Compact and smooth the mortar using a hand or power trowel. Allow to cure. (Cure times vary depending on environmental conditions.)

## BONDING / BROADCAST COAT

### MIXING AND APPLICATION

1. Premix 3746A (resin) using a low-speed drill and Jiffy blade. Mix for one minute until uniform, exercising caution not to whip air into the material.
2. Add 2 parts 3746A (resin) to 1 part 3746B (hardener) by volume. Mix with low-speed drill and Jiffy blade for three minutes until uniform.
3. Apply 3746 using a spring steel trowel or red rubber squeegee and backroll with a 3/8" nap roller at a spread rate of 100 sq. ft. per gallon.
4. Broadcast 6750DB/6755DB vinyl chips to excess into the wet bonding coat. Allow to cure before applying seal coat. (Cure times vary depending on environmental conditions.)

## SEAL COAT

### MIXING AND APPLICATION

1. Sweep off using a clean, stiff-bristled broom or vacuum to remove excess aggregate. Premix 3746A (resin) using a low-speed drill and Jiffy blade. Mix for one minute until uniform, exercising caution not to whip air into the material.
2. Add 2 parts 3746A (resin) to 1 part 3746B (hardener) by volume. Mix with low-speed drill and Jiffy blade for three minutes until uniform.
3. Apply 3746 using a spring steel trowel or red rubber squeegee and backroll with a 3/8" nap roller at a spread rate of 100 sq. ft. per gallon. Allow to cure 24 hours minimum before opening to traffic.

**NOTE:** Epoxy materials will appear to be cured and "dry to touch" prior to full chemical cross linking. Allow epoxy to cure for 2-3 days prior to exposure to water or other chemicals for best performance.

### APPLICATION EQUIPMENT

#### Brush / Roller

Use 1/4" phenolic core rollers and professional quality, medium-stiff natural bristle brushes.

#### Trowel

Use steel finishing trowel or epoxy mortar power trowel such as one manufactured by Superior.

## CLEANUP

Clean up mixing and application equipment immediately after use. Use toluene or xylene. Observe all fire and health precautions when handling or storing solvents.

## SAFETY PRECAUTIONS

Refer to the SDS sheet before use. Published technical data and instructions are subject to change without notice. Contact your Sherwin-Williams representative for additional technical data and instructions.

## MATERIAL STORAGE

Store materials in a temperature controlled environment (40°F to 90°F) and out of direct sunlight.

Keep resins, hardeners and solvents separated from each other, and away from sources of ignition.

## MAINTENANCE

Occasional inspection of the installed material and spot repair can prolong system life. For specific information, contact the Sherwin-Williams Technical Service Department.

## DISCLAIMER

The information and recommendations set forth in this document are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication.

Consult [www.sherwin-williams.com/resin-flooring](http://www.sherwin-williams.com/resin-flooring) to obtain the most recent Product Data information and Application instructions.

## WARRANTY

The Sherwin-Williams Company warrants our products to be free of manufacturing defects in accord with applicable Sherwin-Williams quality control procedures. Liability for products proven defective, if any, is limited to replacement of the defective product or the refund of the purchase price paid for the defective product as determined by Sherwin-Williams.

NO OTHER WARRANTY OR GUARANTEE OF ANY KIND IS MADE BY SHERWIN-WILLIAMS, EXPRESSED OR IMPLIED, STATUTORY, BY OPERATION OF LAW OR OTHERWISE, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## THE SHERWIN-WILLIAMS DIFFERENCE

Sherwin-Williams High Performance Flooring delivers world-class industry subject matter expertise, unparalleled technical and specification service, and unmatched regional commercial team support to our customers around the globe.

---

### United States & Canada

[sherwin-williams.com/resin-flooring](http://sherwin-williams.com/resin-flooring)  
[swflooding@sherwin.com](mailto:swflooding@sherwin.com)