


## SOFTOP™ TOPFLOOR BC

Sherwin-Williams SofTop Topfloor BC is a 1/8" or 3/16" (3-4 mm) thick flexible epoxy-based floor system that provides several unique benefits including: noise reduction, ergonomics, and resistance to reflective cracking, and damage from dropped tools or equipment. Softop Topfloor BC is fluid applied providing a seamless surface in a smooth or non-skid finish that is chemical resistant and easy to maintain.



### BENEFITS

- Seamless
- Ergonomic, anti-fatigue
- Quiet
- Impact, crack and chip resistant
- Acceptable for use in USDA inspected facilities

### USES

- Manufacturing
- Food and beverage facilities (areas where temperatures will not exceed 120°F in service)
- Process areas, work stations
- Animal holding, surgery rooms
- Corridors, hotel/convention centers

- ① Primer
- ② Bonding Coat
- ③ Broadcast / Rubber
- ④ Grout Coat
- ⑤ Seal Coat

### TYPICAL PHYSICAL PROPERTIES

<b>Color</b>	Standard colors Can be tinted at local SW store
<b>Adhesion</b> ACI 503R	100% concrete failure, >350 psi
<b>Elongation</b> ASTM D 412	80%
<b>Flammability</b> ASTM E 648 Critical Radiant Flux	Class I
<b>Impact Resistance</b> ASTM D 4226	>160 in./lbs. (160 lb. load)
<b>Noise Reduction Coefficient</b> ASTM C 423	0.05
<b>Residual Indentation</b> ASTM F 1914	1% thickness (140 lb. load)
<b>Tensile Strength</b> ASTM D 412	1,500 psi
<b>Thermal Cycling</b> ASTM C 884	No cracking

## INSTALLATION

Sherwin-Williams materials shall only be installed by approved contractors. The following information is to be used as a guideline for the installation of the SofTop Topfloor BC. Contact the Sherwin-Williams Technical Service Department for assistance prior to application.

### SURFACE PREPARATION - GENERAL

Sherwin-Williams systems can be applied to a variety of substrates if the substrate is properly prepared. Preparation of surfaces other than concrete will depend on the type of substrate, such as wood, concrete block, quarry tile, etc. Should there be any questions regarding a specific substrate or condition, please contact the Sherwin-Williams Technical Service Department prior to starting the project. Refer to Surface Preparation Form G-1.

### SURFACE PREPARATION - CONCRETE

Concrete surfaces shall be abrasive blasted to remove all surface contaminants and laitance. The prepared concrete shall have a surface profile depending upon system selected. Refer to Form G-1.

After initial preparation has occurred, inspect the concrete for bug holes, voids, fins and other imperfections. Protrusions shall be ground smooth while voids shall be filled with a system compatible filler. For recommendations, consult the Sherwin-Williams Technical Service Department.

## TEMPERATURE

Throughout the application process, substrate temperature should be 60-90°F. Substrate temperature must be at least 5°F above the dew point. Applications on concrete substrate should occur while temperature is falling to lessen off gassing. The material should not be applied in direct sunlight, if possible. Protect material from freezing prior to installation.

## APPLICATION INFORMATION — SURFACE PREP PROFILE CSP 3-4

VOC MIXED	APPLICATION STEP	MATERIAL	MIXED RATIO	THEORETICAL COVERAGE PER COAT CONCRETE	PACKAGING
<50 g/L	Primer (on or below grade)	3579	2:1	250-300 sq ft / gal	3 or 15 gal
<100 g/L 0	Bonding Coat Broadcast Rubber	3555 5601	1:1 To Excess	40 sq. ft. / gal 25 lbs. / 100 sq. ft.	2 or 10 gals 50 lb. bag
<100 g/L	Grout	3555	1:1	80-100 sq. ft./ gal	2 or 10 gals
For smooth finish - sand surface with 80 grit screens					
<50 g/L	Seal Coat	4687	2:1	250-400 sq. ft. / gal	3 or 15 gals

For different optional seal coats such as Resutile 4685 or Elladur 4844, consult individual technical data sheet for mixing and application instructions.

## PRIMER

### MIXING AND APPLICATION

1. Add 2 parts 3579A (resin) to 1 part 3579B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes until uniform. To ensure proper system cure and performance, strictly follow mix ratio recommendations.
2. 3579 may be applied via roller or brush. Apply at 250-300 square feet per gallon to yield 5-6 mils WFT evenly with no puddles making sure of uniform coverage. Coverage will vary depending upon porosity of the substrate and surface texture.
3. Wait until primer is tacky (usually one hour), before applying the membrane. If primer is not going to be topped within open time, broadcast silica sand into resin lightly but uniformly and allow to cure overnight.

**NOTE:** Primer not required for slabs over occupied space with a CSP 3 minimum profile.

## BINDER / BROADCAST RUBBER MIXING AND APPLICATION

1. Premix 3555A (resin) using a low speed drill and Jiffy blade. Mix for one minute until uniform, exercising caution not to whip air into the material.
2. Add 1 part 3555A to 1 part 3555B by volume. Mix with low speed drill and Jiffy blade for three minutes until uniform.
3. Immediately pour the mixed material onto the substrate. Allow to self-level and apply at 40 feet per gallon. Allow to self-level, then broadcast 25 lbs. per 100 sq. ft. of 5601 rubber aggregate into wet 3555 resin to refusal.
4. Allow material to cure 18-24 hours.

**NOTE:** For 3/16" repeat broadcast into second coat of 3555 at 80-100 feet per gallon.

## GROUT

### MIXING AND APPLICATION

1. Premix 3555A (resin) using a low speed drill and Jiffy blade. Mix for one minute until uniform, exercising caution not to whip air into the material.
2. Add 1 parts 3555A (resin) to 1 part 3555B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes until uniform.
3. Immediately pour the mixed material onto the substrate and pull out using a 1/8" v-notched squeegee to yield 16-20 mils WFT and cross roll with a 3/8" nap roller.

4. Allow to cure overnight at 73°F surface temperature. Material cures slower at lower temperatures. After overnight cure, the broadcast texture can be reduced by sanding the surface with 80 grit paper/screens, which results in a smoother surface but is not required.
5. After the membrane is cured, check for surface blush. Remove any blush with detergent wash completing installation of desired system.

## SEAL COAT

### MIXING AND APPLICATION

DO NOT PREMIX PART B HARDENER.

1. Premix 4687A (resin) using a low speed drill and Jiffy blade. Mix for one minute until uniform, exercising caution not to introduce air into the material.
2. Add 2 parts 4687A (resin) to 1 part 4687B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes until uniform. To ensure proper system cure and performance, strictly follow mix ratio recommendations.
3. Apply 4687 using a 1/4" nap roller at a spread rate of 250-400 square feet per gallon, evenly, with no puddles making sure of uniform coverage. Take care not to puddle materials and ensure even coverage. If a second coat is required, the surface must be abraded with 80-120 grit paper or screen and tack wiped prior to second application.
4. Allow to cure 24 hours minimum before opening to traffic. In cool and/or high humidity conditions, a surface film may form which can be washed with soap and water. Resutile 4685 or Elladur 4844, consult individual technical data sheet for mixing and application instructions.

## CLEANUP

Clean up mixing and application equipment immediately after use. Use toluene or xylene. Observe all fire and health precautions when handling or storing solvents.

## SAFETY PRECAUTIONS

Refer to the SDS sheet before use. Published technical data and instructions are subject to change without notice. Contact your Sherwin-Williams representative for additional technical data and instructions.

## MATERIAL STORAGE

Store materials in a temperature controlled environment (50-90°F) and out of direct sunlight. Keep resins, hardeners, and solvents separated from each other and away from sources of ignition.

## MAINTENANCE

Occasional inspection of the installed material and spot repair can prolong system life. For specific information, contact the Sherwin-Williams Technical Service Department.

## DISCLAIMER

The information and recommendations set forth in this document are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication.

Consult [www.sherwin-williams.com/resin-flooring](http://www.sherwin-williams.com/resin-flooring) to obtain the most recent Product Data information and Application instructions.

## WARRANTY

The Sherwin-Williams Company warrants our products to be free of manufacturing defects in accord with applicable Sherwin-Williams quality control procedures. Liability for products proven defective, if any, is limited to replacement of the defective product or the refund of the purchase price paid for the defective product as determined by Sherwin-Williams.

NO OTHER WARRANTY OR GUARANTEE OF ANY KIND IS MADE BY SHERWIN-WILLIAMS, EXPRESSED OR IMPLIED, STATUTORY, BY OPERATION OF LAW OR OTHERWISE, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## THE SHERWIN-WILLIAMS DIFFERENCE

Sherwin-Williams High Performance Flooring delivers world-class industry subject matter expertise, unparalleled technical and specification service, and unmatched regional commercial team support to our customers around the globe.

### United States & Canada

[sherwin-williams.com/resin-flooring](http://sherwin-williams.com/resin-flooring)  
[swflooding@sherwin.com](mailto:swflooding@sherwin.com)